

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor. The components are numbered 1 through 21. The assembly sequence from left to right is as follows: Component 1 (a large housing) is joined to Component 11 (a small bracket). Component 12 (a small valve or plug) is inserted into Component 13 (a larger housing). Component 14 (a lever or arm) is attached to Component 13. Component 15 (a circular plate with pins) is joined to Component 16 (a central shaft or pin). Component 17 (a small housing) is attached to Component 16. Component 18 (a small pin or screw) is inserted into Component 17. Component 19 (a large housing) is joined to Component 20 (a central shaft or pin). Component 21 (a small pin or screw) is inserted into Component 20.

1 Cover	6 Stator	11 Brush box moulding	16 Slip ring bearing
2 Live side output diodes	7 Field winding	12 Rectifier pack	17 Rotor
3 Earth side output diodes	8 Shaft key	13 Rectifier assembly bolt	18 Drive end bearing
4 Field diodes	9 Drive end bracket	14 Slip ring end bracket	19 Fan
5 Through Bolts	10 Spring washer	15 Slip rings	20 Pulley
			21 nut

These alternators are identical in mechanical construction, differing only in the number of turns and the wire gauge on the stator winding which result in alternative electrical performance characteristics (Fig. 3).

Rectification of alternator output is achieved by six silicon diodes housed in a rectifier pack and connected as a 3-phase full wave bridge circuit. The rectifier pack is attached to the outer face of the slip-ring end bracket, and contains also three 'field' diodes. At normal operating speeds, rectified current from the stator output windings flows through these diodes to provide self-excitation of the rotor field, via brushes bearing on face type slip-rings, the latter being carried on a small diameter moulded drum attached to the rotor shaft outboard of the slip-ring end bearing.

Early production model 15AC and 16AC alternators incorporate a rectifier pack of a different pattern to that shown in Fig. 1. The earlier unit is mounted partly on the brushbox moulding and partly on the slip-ring end bracket. The dismantling instructions in 4b refer to the later pattern rectifier pack only.

When checking the field diodes on the earlier unit note that the insulating mounting bracket is positioned between the diodes and their heat sink.

The alternator output is controlled by an electronic voltage regulator unit (see Part B).




Fig. 2 The charging circuit

Warning Light

The additional 'field' diodes enable a simple charge-indicator warning light to be used (Fig. 2). When the ignition is switched on, the warning light is connected to the battery, the circuit being completed by way of the alternator field winding and the regulator. The bulb is then lit fully. This small current, flowing in the field winding, sets up a flux which supplements the residual flux in the rotor and aids the initial build-up of stator voltage as the rotor begins to rotate when the engine is started.

As rotor speed and generated voltage increases, the field current supplied by the stator winding through the 'field' diodes increases correspondingly until finally the alternator becomes self-excited. During the rise in stator generated voltage (reflected at terminal IND) the brilliance of the warning light is gradually reduced. At approximately the speed at which the alternator commences to charge, the voltage at the IND terminal equals that at the battery side of the warning light, and the latter is extinguished. Thus, illumination of the warning light under normal running conditions indicates that the alternator is not functioning correctly.




Fig. 3 Typical performance curve (alternator hot)

2. ROUTINE MAINTENANCE

(a) Cleaning

Wipe away any dirt or oil which may have collected around the apertures in the slip-ring end bracket and moulded cover.

(b) Belt Adjustment

Occasionally inspect the driving belt for wear and tension. Refer to the vehicle manufacturer's handbook for the correct method of adjusting belt tension.

Important. To avoid bearing damage when adjusting belt tension, apply leverage only on the alternator drive end bracket, not on any other part of the alternator. The lever should be of a soft material, preferably wood.

(c) Lubrication

The bearings are packed with grease during assembly, and will normally require no further lubrication during their service life.

(d) Connexions

All electrical connexions in the charging circuit (including those at the battery) must be maintained tight at all times.

3. TECHNICAL DATA

Earth polarity of system	NEGATIVE only
Nominal voltage	12
Nominal d.c. output (hot)	28 amp. (15AC)
at 14.0V and 6,000 rev/min.	34 amp. (16AC)
Max. permissible rotor speed	12,500 rev/min
Stator phases	3
Stator winding connexion	Star
Number of rotor poles	12
Resistance of rotor winding	4.33 $\pm 5\%$ ohms at 20°C.

Brush spring tension	7-10 oz (198-283 g) with brush face flush with brushbox housing
----------------------	---

- 1 Live side output diodes (3)
- 2 Earth side output diodes (3)
- 3 Field feed diodes (3)
- 4 Stator winding
- 5 Field winding
- 6 Slip rings
- 7 12 volt battery
- 8 0-40 or 0-60 ammeter
- 9 12 volt 2.2 watt bulb
- 10 0-20 voltmeter
- 11 0-15Ω, 35 amp variable resistor




Fig. 4 Alternator output test circuit

Alternator Models 15AC and 16AC

PART SECTION

A 4

4. SERVICING

Battery cables must not be disconnected while the engine is running or damage to semiconductor devices may occur. It is also inadvisable to break or make any other connexions in the alternator circuit while the engine is running.

(a) Testing the Alternator in Position

First check the driving belt for wear and tension. Also ensure that all connexions in the charging circuit are tight.

The nominal hot output ratings are given in para. 3. These figures may be exceeded slightly when the alternator is running cold. To avoid misleading results, the following test procedure should therefore be carried out with the alternator running as near to its normal operating temperature as possible.

Withdraw the moulded terminal connector from the alternator, and connect a test circuit as shown in Fig. 4. Observe carefully the polarity of battery and alternator terminals – reversed connexions will damage the alternator diodes.

The resistor across the battery terminals must not be left connected for longer than is necessary to carry out the following test.

Start the engine. At 1,500 alternator rev/min, the test circuit bulb should be extinguished. Increase engine speed until the alternator is running at 6,000 rev/min approximately, and adjust the variable resistance until the voltmeter reads 14.0 volts. The ammeter reading should then be approximately equal to the rated output (para. 3). Any appreciable deviation from this figure will necessitate the alternator being removed from the engine for further examination (para. 4b).

Failure of one or more of the diodes will be indicated in the above test by the effect on alternator output, and also in some instances by abnormally high alternator temperature and noise level. The table shows how diode failure will influence test results, and para. 4g gives information on testing the diodes.

SYMPTOMS				
Warning light	Alternator			Probable fault and associated damage
	Temperature	Noise	Output	
Normal at stand-still, goes out at cut-in speed but then glows progressively brighter as speed increases	High	Normal	Higher than normal at 6,000 rev/min. 15AC. 35 amp. approx. 16AC. 40 amp. approx.	Live side output diode open-circuit. (May damage rotor winding and reg. output stage, overheat brushboxes and blow warning light)
Light out under all conditions	High	Excessive	Very low at 6,000 rev/min. 10 amp. approx.	Live side output diode short-circuit. (May cause failure of associated 'field' diode)
Normal at stand-still, dims appreciably at cut-in and gets progressively dimmer at higher speeds	Normal	Excessive	Poor at low speed. Slightly below normal at 6,000 rev/min. 15AC. 26 amp. approx. 16AC. 32 amp. approx.	Earth side output diode open-circuit.
Normal at stand-still, dims slightly at cut-in and remains so through-out speed range	Normal	Excessive	Very low at all speeds above cut-in. 7 amp. approx.	Earth side output diode short-circuit. (The same symptoms would be apparent if one phase winding was shorted to earth)
Normal at stand-still, dims slightly at cut-in and remains so through-out speed range	Normal	Normal	Lower than normal at 6,000 rev/min. 15AC. 23 amp. approx. 16AC. 29 amp. approx.	'Field' diode open-circuit
Normal at stand-still, dims appreciably at cut-in and remains so at higher speeds	Normal	Excessive	Very low at 6,000 rev/min. 7 amp. approx.	'Field' diode short-circuit

Alternator Models 15AC and 16AC

If the foregoing test shows the alternator to be giving satisfactory performance, disconnect the test circuit and reconnect the alternator terminal connector. Now connect a low-range voltmeter (Fig. 5) between the positive terminal of the alternator (the moulded terminal connector is open ended to facilitate this) and the positive terminal of the battery.




Fig. 5 Charging circuit voltage drop testing (insulated side)

Switch on the headlamps, start the engine and increase speed until the alternator runs at approximately 6,000 rev/min. The voltmeter reading should not exceed 0.5 volt. Transfer the voltmeter connections to the negative terminals (Fig. 6) of alternator and battery. The meter reading should not exceed 0.25 volt.

If either reading is in excess of the value quoted, a high resistance in that portion of the charging circuit is indicated, which must be traced and remedied.




Fig. 6 Charging circuit voltage drop testing (earth side)

(b) Electrical Test Procedure

The following instructions cover the dismantling required to enable the alternator to be tested electrically. If, as a result of these tests (or because the rotor bearings are to be replaced) further dismantling becomes necessary, proceed as described in 4(h).

Disconnect the battery and alternator cables and remove the alternator from the vehicle.

Withdraw the two moulded cover securing screws and remove the cover.

Unsolder the three stator connexions to the rectifier assembly noting the order of connexion. (See para. 4g for soldering procedure).

Withdraw the two brush moulding securing screws and slacken the nut on the rectifier assembly bolt, allowing the brush moulding and rectifier assembly to be withdrawn together with the short cable which joins them.

(c) Inspection of Brushgear

The brush length when new is $\frac{1}{2}$ " (12.6 mm). The serviceability of a brush may be gauged by measuring the amount by which it protrudes beyond the brush-box moulding when in the free position. For a brush to remain serviceable the amount protruding should exceed 0.2" (5 mm). Renew the brush assemblies if the brushes are worn to or below this amount.

Check the brush spring pressures using a push-type spring gauge. This should indicate 7-10 oz (198-283 g) when the brush is pushed back against the spring until the brush face is flush with the housing. Replace a brush assembly which gives a reading appreciably outside these limits where this is not due to the brush movement being impeded for any reason. Clean a sticking brush with a petrol-moistened cloth or, if necessary, by lightly polishing the brush sides on a smooth file.

(d) Inspection of Slip-rings

The surfaces of the slip-rings should be smooth and uncontaminated by oil or other foreign matter. Clean the surfaces using a petrol-moistened cloth, or if there is evidence of burning, very fine glasspaper. On no account must emery cloth or similar abrasive be used. No attempt must be made to machine the slip-rings as any eccentricity in the machining may adversely affect the high-speed performance of the alternator.




Fig. 7 Measuring rotor winding resistance with ohmmeter

(e) Rotor

Note: For clarity, the illustration of the electrical testing of the rotor and stator show these components isolated from the remainder of the alternator.




Fig. 8 Measuring rotor winding resistance with battery and ammeter

Test the rotor winding by connecting either an ohmmeter (Fig. 7) or a 12-volt battery and ammeter (Fig. 8) between the slip-rings. The resistance should be approximately 4.3 ohms, or the value of current approximately 3 amperes.




Fig. 9 Insulation test of rotor winding

Test for defective insulation between one of the slip-rings and one of the rotor poles using a 110-volt a.c. mains supply and a 15-watt test lamp (Fig. 9). If the lamp lights, the coil is earthed to the rotor core and a replacement rotor/slip-ring assembly must be fitted.

No attempt must be made to machine the rotor poles or to straighten a distorted shaft.




Fig. 10 Stator winding continuity test

(f) Stator

Check the continuity of the stator windings by first connecting any two of the three stator cables in series with a 12-volt battery and test lamp of not less than 36-watts (Fig. 10). Repeat the test, replacing one of the two cables by the third cable. Failure of the test lamp to light on either occasion means that part of the stator winding is open-circuit and a replacement stator must be fitted.




Fig. 11 Insulation test of stator windings

Test for defective insulation between stator coils and the lamination pack with the mains test lamp (Fig. 11). Connect the test probes between any one of the three cable ends and the lamination pack. If the lamp lights, the stator coils are earthing and a replacement stator must be fitted.




Fig. 12 Simple test for diodes

(g) Diodes

In the event of a fault in one or more of the diodes being indicated by the alternator output test (para. 4a), the stator winding connections to the rectifier pack must be unsoldered (para. 4b).

Connect each of the nine diode pins in turn in series with a 1.5 watt test bulb and one terminal of a

Alternator Models 15AC and 16AC

12-volt battery (Fig. 12). Connect the other battery terminal to the particular heat sink on the rectifier pack into which the diode under test is soldered. Next, reverse the connexions to diode pin and heat sink. The bulb should light in one direction only. Should the bulb light in both tests, or not light in either, the diode is defective and a new rectifier pack must be fitted.

When re-soldering the stator cables to the diode pins use only 'M' grade 45-55 tin-lead solder. Take great care to avoid overheating the diodes or bending the diode pins. The diode pins should be lightly gripped with a pair of long-nosed pliers (which act as a thermal shunt) and soldering must be carried out as quickly as possible. The operation is shown in Fig. 13.




Fig. 13 Use of thermal shunt when soldering diode connexions

(h) Further Dismantling

If as a result of the foregoing electrical tests further dismantling is necessary proceed as follows:

Withdraw the three through bolts. Separate the slip-ring end bracket and stator assembly from the rotor and drive-end bracket — preferably by sleeving a metal tube about 3" long over the slip-ring moulding so as to engage with the outer ring of the slip-ring end bearing and then carefully driving the bearing from its housing with the alternator positioned vertically, fan lowermost. The tube should be 1.320" (33.53 mm) outside diameter and bored out to 1.240" (31.5 mm) for about half of its length. Carefully file away any surplus solder from the field winding terminals which may prevent the tubing from sleeving over the slip-ring moulding. The less preferred method of separating the slip-ring end bracket and stator assembly from the rotor and drive-end bracket is to insert a lever between the stator and the drive-end bracket and carefully prise the two apart until the slip-ring end bearing is clear of its housing.

If necessary, the rotor shaft can be pressed out from the drive-end bracket having first removed the shaft nut, washers, pulley, fan and shaft key.

(i) Bearings

The need for bearing replacement during the

service life of the alternator is extremely unlikely provided the alternator is mounted correctly and belt tension maintained as recommended. However, should bearing replacement become necessary, proceed as follows:

Drive-end Bearing

Dismantle the alternator as described in 4b (it is not necessary to unsolder the rectifier assembly) and also as in 4h including the separation of the rotor from the drive-end bracket.

The drive-end bearing assembly can be withdrawn following removal of the circlip — see Fig. 1 for details of the bearing assembly.

Slip-ring End Bearing

Dismantle the alternator as described for the drive-end bearing. Unsolder the field winding connexions to the slip-ring moulding assembly which can then be withdrawn from the rotor shaft. Extract the bearing from the shaft, noting that the shielded side of the bearing faces the slip-ring end moulding. Fit the new bearing and re-engage the slip-ring moulding with the slot in the rotor shaft. Finally, remake the field-to-slip-ring connexions using Fry's H.T.3 solder.

When required, the correct lubricant for the alternator bearings is Shell Alvania 'RA'.

(k) Reassembly

Reassembly of the alternator is a reversal of the dismantling procedure given in 4b and h. Ensure that the slip-ring end bearing is positioned as far as it will go along the rotor shaft in the direction of the field assembly. Ensure that the brushes are entered in their housing before refitting the brush moulding. Tighten the through bolts evenly. If the rotor and drive-end bracket have been separated, support the inner ring of the drive-end bearing with a suitably-dimensioned tube for the re-assembling operation. Do not use the drive-end as a support for the bearing while fitting the rotor.

5. PRECAUTIONS

It is important to observe the following precautions when servicing vehicles fitted with alternator charging systems:

- Battery cables must not be disconnected while the engine is running, or damage to semiconductor devices may occur. Do not break or make any other connexions in the charging circuit while the engine is running.
- All electrical connexions in the charging circuit must be maintained tight at all times.
- Care must be taken when connecting the battery, either on the vehicle or in a test circuit, to ensure the correct polarity.
- If electric arc welding is being carried out on any part of the vehicle, the connectors should be removed from the alternator and regulator to avoid possibility of damage to semiconductor devices.