

THE

FUEL PUMP

Type
AUF 500

(SPECIFICATION RANGE: AUF 400 TO AUF 499)

**DISMANTLING AND REASSEMBLING
INSTRUCTIONS**

MANUFACTURED
by


THE S.U. CARBURETTOR COMPANY LIMITED

Proprietors: MORRIS MOTORS LIMITED

WOOD LANE • ERDINGTON • BIRMINGHAM 24
TELEPHONE: ERDINGTON 7371 (9 lines) TELEGRAMS: CARBURFLEX, BIRMINGHAM



THE S.U. TYPE AUF 500 RANGE PUMP



AUF 500: Two inlet connections, pumping units not normally intended to operate simultaneously.

B3272

No.	Description	No.	Description	No.	Description
1.	Pump body.	20.	Nut—terminal.	39.	Washer—sealing.
2.	Diaphragm and spindle assembly.	21.	Washer—end cover seal.	40.	Filter.
3.	Roller—armature centralizing.	22.	Contact blade.	41.	Gasket—diaphragm.
4.	Washer—Impact.	23.	Washer—5 B.A.	42.	Band—sealing.
5.	Spring—armature.	24.	Screw—contact blade—5 B.A.	43.	Valve—vent.
6.	Housing—coil.	25.	Condenser.	44.	Joint—inlet air bottle.
7.	Screw—securing housing—2 B.A.	26.	Clip—condenser.	45.	Cover—inlet air bottle.
8.	Connector—earth.	27.	Washer—spring—2 B.A.	46.	Washer—dished.
9.	Screw—4 B.A.	28.	Screw—pedestal to housing—2 B.A.	47.	Washer—spring.
10.	Washer—spring—4 B.A.	29.	End cover.	48.	Screw—cover.
11.	Tag—terminal—5 B.A.	30.	Washer—shakeproof.	49.	Connection—inlet.
12.	Tag—terminal—2 B.A.	31.	Connector—Lucar.	50.	Washer—sealing.
13.	Tag—earth—2 B.A.	32.	Nut—2 B.A.	51.	Cover—delivery air bottle.
14.	Pin—rocker pivot.	33.	Sleeve—insulating.	52.	Screw—cover.
15.	Rocker mechanism.	34.	Plate—clamp.	53.	'O' ring—rubber.
16.	Pedestal.	35.	Screw—plate.	54.	Diaphragm—plastic.
17.	Stud terminal.	36.	Cap—valve.	55.	Washer—sealing.
18.	Washer—spring.	37.	Valve—inlet.	56.	Gasket (single layer diaphragm only).
19.	Washer—lead.	38.	Valve—outlet.		

DISMANTLING

Contact breaker

1. Remove the insulated sleeve (33), terminal nut (32), and connector (31), together with its shakeproof washer. Remove the tape seal (if fitted) and take off the end-cover.
2. Unscrew the 5 B.A. screw (24) which holds the contact blade (22) to the pedestal (16) and remove the condenser (25) (if fitted) from its clip. This will allow the washer (23), the long-coil lead (11), and the contact blade to be removed.

Coil housing and diaphragm

3. Unscrew the coil housing securing screws (7), using a thick-bladed screwdriver to avoid damaging the screw heads.
4. Remove the earthing screw (9).
5. The coil housing (6) may now be removed from the body (1). Next remove the diaphragm and spindle assembly (2) by taking hold of the diaphragm and unscrewing it anti-clockwise until the armature spring (5) pushes the diaphragm away from the coil housing. It is advisable to hold the housing over the bench so that the 11 brass rollers (3) will not fall on the floor. The diaphragm and its spindle are serviced as a unit and should not be separated.
6. Repeat these operations on the remaining pump unit.

Pedestal and rocker


7. Remove the end-cover seal washer (21), unscrew the terminal nut (20), and remove the lead washer (19). This will have flattened on the terminal tag and thread and is best cut away with cutting pliers or a knife. Unscrew the two 2 B.A. screws (28) holding the pedestal to the coil housing, remove the earth terminal tag (13) together with the condenser clip (26) (if fitted). Tip the pedestal and withdraw the terminal stud (17) from the terminal tag (12). The pedestal (16) may now be removed with the rocker mechanism (15) attached.
8. Push out the hardened steel pin (14) which holds the rocker mechanism to the pedestal and separate the two.
9. Repeat these operations on the remaining pump unit.

Body and valves

10. Unscrew the inlet and outlet unions.
11. Unscrew the self-tapping screws (35) securing the clamp plate (34) holding the valve assemblies on both sides of the body, remove the valve assemblies (37 and 38) with the perforated caps (36), filters (40) and joint washers (39).
12. Remove the inlet air bottle cover by unscrewing the single 2 B.A. securing screw (48).

Note. Dismantling of the delivery air bottle should only be undertaken if it is faulty in operation and if the necessary equipment for pressure-testing after assembly is available. On this understanding proceed as follows:

13. Remove the delivery air bottle cover by unscrewing the



A9338A

Fig. 2. The correct assembly of components on the terminal stud

four screws. Remove the 'O' ring (53), the plastic diaphragm (54), and joint washer (55).

INSPECTION


If gum formation has occurred in the fuel used in the pump, the parts in contact with the fuel will have become coated with a substance similar to varnish. This has a strong stale smell and may attack the neoprene diaphragm. Brass and steel parts so affected can be cleaned by being boiled in a 20 per cent. solution of caustic soda, dipped in a strong nitric acid solution and finally washed in boiling water. Light alloy parts must be well soaked in methylated spirits and then cleaned.

1. Clean the pump and inspect for cracks, damaged joint faces, and threads.
2. Examine the plastic valve assemblies for kinks or damage to the valve plates. They can best be checked by blowing and sucking with the mouth. Check that the narrow tongue on the valve cage, which is bent over to retain the valve, and to prevent it being forced out of position, has not been distorted but allows a valve lift of approximately $\frac{1}{16}$ in. (1.6 mm.). (see Fig. 1).
3. Examine the delivery air bottle diaphragm and end-cover for damage. If in doubt, renew the diaphragm. Examine the inlet air bottle cover for damage.
4. Examine the valve recesses in the body for damage and corrosion; if it is impossible to remove the corrosion, or if the recess is pitted, the body must be discarded.
5. Clean the filters with a brush, examine for fractures, renew if necessary.
6. Examine the coil lead tags for security and the lead insulation for damage.
7. Examine the contact breaker points for signs of burning and pitting; if this is evident, the rocker assembly and spring blade must be renewed.
8. Examine the pedestal for cracks or other damage, in particular to the narrow ridge on the edge of the rectangular hole on which the contact blade rests.
9. If fitted, examine the non-return vent valve in the end-cover for damage, ensure that the small ball valve is free to move.
10. Examine the diaphragm for signs of deterioration.
11. Renew the following parts: all fibre washers, gaskets, and 'O' section sealing rings, rollers showing signs of wear on periphery, damaged bolts, and unions.

ASSEMBLY

Pedestal and rocker

Note. The steel pin which secures the rocker mechanism to the pedestal is specially hardened and must not be replaced by other than a genuine S.U. part.



A9304

Fig. 1. The valve (inlet and outlet)
A = $\frac{1}{16}$ in. (1.6 mm.)




Fig. 3. Fitting the rocker assembly to the pedestal. (Inset) the correct position of the centre toggle spring

1. Invert the pedestal and fit the rocker assembly to it by pushing the steel pin (1) (Fig. 3) through the small holes in the rockers and pedestal struts. Then position the centre toggle so that, with the inner rocker spindle in tension against the rear of the contact points, the centre toggle spring is above the spindle on which the white rollers run. This positioning is important to obtain




Fig. 4. Attaching the pedestal to the coil housing

the correct 'throw over' action. It is also essential that the rockers are perfectly free to swing on the pivot pin and that the arms are not binding on the legs of the pedestal. If necessary the rockers can be squared up with a pair of thin-nosed pliers.

2. Assemble the square-headed 2 B.A. terminal stud to the pedestal, the back of which is recessed to take the square head.
3. Assemble the 2 B.A. spring washer (1) (Fig. 4), and put the terminal stud through the 2 B.A. terminal tag (2), then fit the lead washer (3) and the coned nut with its coned face to the lead washer. (This makes better contact than an ordinary flat washer and nut.) Tighten the 2 B.A. nut and finally add the end-cover seal washer (5).




Fig. 5. Fitting the diaphragm to the coil housing. Note the impact washer (1)




Fig. 6. Inserting the diaphragm centralizing rollers

4. Assemble the pedestal to the coil housing (Fig. 4) by fitting the two 2 B.A. pedestal screws (6), ensuring that the spring washer (7) on the left-hand screw (9 o'clock position) is between the pedestal and the earthing tag (8). When a condenser is fitted, its wire clip base is placed under the earthing tag and the spring washer is dispensed with.
5. Tighten the screws, taking care to prevent the earthing tag (8) from turning, as this will strain or break the earthing flex. Do not overtighten the screws or the pedestal will crack. Repeat these operations on the remaining pedestal and rocker assembly.

Do not fit the contact blade at this stage.

Diaphragm assembly

6. Place the armature spring into the coil housing with its larger diameter towards the coil (Fig. 5).
7. Before fitting the diaphragm make sure that the impact washer is fitted to the armature. (This is a small neoprene washer that fits in the armature recess.) Do not use jointing compound or dope on the diaphragm.
8. Fit the diaphragm by inserting the spindle in the hole in the coil and screwing it into the threaded trunnion in the centre of the rocker assembly.
9. Screw in the diaphragm until the rocker will not 'throw over'; this must not be confused with jamming the armature on the coil housing internal steps.
10. Fit the 11 brass centralizing rollers (Fig. 6) by turning back the diaphragm edge and dropping the rollers into the coil recess. The pump should be held in the left hand, rocker end downwards, to prevent the rollers from falling out.

On later-type rocker mechanisms with adjustable fingers fit the contact blade and adjust the finger settings as described under those headings, then carefully remove the contact blade.




Fig. 7. Setting the diaphragm. Unscrew until the rocker just 'throws over'




Fig. 8. Fitting the roller retaining fork

11. Holding the coil housing assembly in the left hand in an approximately horizontal position (see Fig. 7), push the diaphragm spindle in with the thumb of the right hand, pushing firmly but steadily. Unscrew the diaphragm, pressing and releasing with the thumb of the right hand until the rocker just 'throws over'. Now turn the diaphragm back (unscrew) to the nearest hole and again 4 holes (two-thirds of a complete turn). The diaphragm is now correctly set.

12. Press the centre of the armature and fit the retaining fork at the back of the rocker assembly (Fig. 8). This is done to prevent the rollers from falling out when the coil housing is placed on the bench prior to fitting the body, and is not intended to stretch the diaphragm before tightening the body screws.

Repeat these operations on the remaining diaphragm assembly.

Body components

13. In the AUF 500 range of pumps the valve assemblies are retained internally in the body by a clamp plate secured with self-tapping screws (see Fig. 9). The inlet valve recess in the body is deeper than the outlet valve recess to allow for the filter and extra washer.

Another feature of the pumps is the incorporation of an air bottle on both the inlet and delivery sides. The inlet air bottle is a chamber in the body casting, blanked off by a simple cover and joint washer, held in position by a single screw.

The delivery air bottle is formed by a flexible plastic diaphragm, separating the delivery chamber in the body from a sealed volume of air contained in the air bottle cover. This cover is secured by four screws and sealed by an 'O' section sealing ring and joint washer.

14. Screw in the inlet and outlet connections with their sealing rings.




Fig. 9. The valve assembly, AUF 500 range

1. Outlet.

2. Inlet.




Fig. 10. The delivery air bottle, AUF 500 range pumps

15. Assemble the outlet valve components into the outlet recess in the following order: first a joint washer, then the valve assembly, tongue side downwards, then the perforated cap.
16. Assemble the inlet valve into the recess as follows: first a joint washer, then the filter, dome side downwards, then another joint washer, followed by the valve assembly, tongue side upwards, then the perforated cap.
17. Take care that both assemblies nest down evenly into their respective recesses. Place the clamping plate on the cap top and tighten down onto the body with the two screws.
18. Repeat these operations on the remaining valve assembly.
19. Replace the inlet air bottle cover with its joint washer and tighten down the central screw.
20. Place a sealing washer in the bottom of the delivery air bottle recess, place the plastic diaphragm, dome side downwards, then add the 'O' section sealing ring and tighten down the cap with its four screws. The pump should be pressure-tested after disturbance of the delivery air bottle.

Body attachment

21. Fit the joint washer to the body, aligning the screw holes. Offer up the coil housing to the body, ensuring a good seating between them.
22. Line up the six securing screw holes, making sure that the cast lugs in the coil housing are at the bottom, insert the six 2 B.A. screws finger-tight.
23. Fit the earthing screw with its Lucar connector.
24. Remove the roller-retaining fork before tightening the body securing screws, making sure that the rollers retain their position; a displaced roller will cut the diaphragm. It is not necessary to stretch the diaphragm before tightening the securing screws.
25. Tighten the securing screws in sequence as they appear diametrically opposite each other.




Fig. 11. Setting the correct relative position of blade and rocker contact points




Fig. 12. Setting the contact blade to ensure contact with the pedestal ridge

Contact blade

26. Fit the contact blade (2) (Fig. 11) and coil lead (1) to the pedestal (3) with the 5 B.A. washer and screw. When a condenser is fitted the tag on it is placed under the coil lead tag.
27. Adjust the contact blade so that the contact points on it are a little above the contact points on the rocker when the points are closed (see Fig. 11), also that when the contact points make or break, one pair of points wipes over the centre line of the other in a symmetrical manner. As the contact blade is provided with a slot for the attachment screw, some degree of adjustment is possible.
28. Tighten the contact blade attachment screw when the correct setting is obtained.

Contact gap setting

29. Check that when the outer rocker is pressed onto the coil housing, the contact blade rests on the narrow rib or ridge which projects slightly above the main face of the pedestal (Fig. 12). If it does not, slacken the contact blade attachment screw, swing the blade clear of the pedestal, and bend it downwards a sufficient amount so that when repositioned it rests against the rib lightly, over-tensioning of the blade will restrict the travel of the rocker mechanism.

Modified rocker assemblies

30. Check the lift of the contact blade tip above the top of the pedestal (A) (Fig. 13) with a feeler gauge, bending the stop-finger beneath the pedestal, if necessary, to obtain a lift of $.035 \pm .005$ in. ($.9 \pm .13$ mm.).
31. Check the gap between rocker finger and coil housing (B) (Fig. 13) with a feeler gauge, bending the stop-finger, if necessary, to obtain a gap of $.070 \pm .005$ in. ($1.8 \pm .13$ mm.).

Earlier-type rocker assemblies

32. Check the gap between the points indirectly by carefully holding the contact blade against the rib on the pedestal without pressing against the tip (see Fig. 14). Then check




Fig. 13. The rocker finger settings on modified rocker assemblies

- | | |
|-----------------------------|------------------------------|
| 1. Pedestal. | 4. Inner rocker. |
| 2. Contact blade. | 5. Trunnion. |
| 3. Outer rocker. | 6. Coil housing. |
| A = $.035$ in. ($.9$ mm.). | B = $.070$ in. (1.8 mm.). |

If a $.030$ in. ($.8$ mm.) feeler will pass between the fibre rollers and the face of the coil housing. If necessary the tip of the blade can be set to correct the gap.




Fig. 14. The contact gap setting on earlier-type rocker assemblies

- | | |
|-----------------------------|------------------|
| 1. Pedestal. | 4. Inner rocker. |
| 2. Contact blade. | 5. Trunnion. |
| 3. Outer rocker. | 6. Coil housing. |
| A = $.030$ in. ($.8$ mm.). | |

End-cover

33. Tuck all spare cable into position so that it cannot foul the rocker mechanism. Ensure that the end-cover seal washer is in position on the terminal stud, fit the bakelite end-cover and lock washer, secure with the brass nut, fit the terminal tag or connector, and the insulated knob.
34. The pump is now ready for test (see leaflet AUA 213 A). After test replace the rubber sealing band over the end cover gap and seal with adhesive tape. This may be removed to improve ventilation when the pump is mounted internally in a moisture-free region but must be retained otherwise.

Note.—The technical information contained in this Service Sheet supersedes any instruction previously published or authorized on this subject by the Company.