
LUCAS WORKSHOP INSTRUCTIONS

CONTROL BOXES MODELS RB106-2 AND RB107**METHOD OF DROP-OFF ADJUSTMENT****Section F-3, Issue 2, Para. 3 (e) (ii).**

The method described in the above para., namely disconnecting the cable from control box terminal A, applies to RB107 (and RB108) control boxes.

For RB106-2 units, it will be necessary to remove the cables from control box terminals A and A1 and connect the cables together.

The remainder of the information is as stated, using a voltmeter connected between terminal A and earth.

