


LUCAS WORKSHOP INSTRUCTIONS

REGULATOR
ADJUSTING
SCREW

CUT-OUT ADJUSTING
SCREW



A I A F D E

CONTROL BOXES MODEL RBI06-2**MODIFIED TERMINALS AND ADJUSTING SCREWS**

As shown above, "Lucar" terminal blades are being fitted on some units in place of the grub screw type terminals previously employed and shown in Section F-3 Issue 2 Fig. 1.

In addition, the regulator and cut-out electrical settings may be found locked with a compression spring located behind the head of each adjusting screw instead of with a locking nut.

