

---

**LUCAS WORKSHOP INSTRUCTIONS**

---

**CONTROL BOXES MODEL RB310****FURTHER INFORMATION ON 24-VOLT UNITS****(a) Current Regulator Setting Speeds**

Current regulators should now be set at the speed specified for the associated voltage regulator. The higher speeds quoted in SECTION F-1 PART B Page 3 for current regulators controlling 24-volt C.A.V. generators are no longer applicable.

**(b) Additional Generator Applications**

- (i) Control Box 37266 quoted as controlling positive earth generator GH45-1 is also used to control negative earth generator G524-6.
- (ii) Control box 37282 quoted as controlling positive earth generator D5L24B-11 is also used to control negative earth generator G524.
- (iii) Control box 37329 quoted as controlling a negative earth version of generator GH45 (The suffix "-1" is incorrect and should be deleted) is also used to control negative earth generator G5A24.

**(c) Superseded Control Box**

Control box 37213 (Volvo, Sweden) is replaced by control box 37327 (Volvo and Scania-Vabis).

**N.B.** The electrical settings on both units must be made with terminals downwards.



BRITISH MADE